

Maintenance

Scheduled Maintenance	Normal Usage		Severe Usage*	
Engine Oil & Filter	Replace	7,500	Replace	3,000
Tire Rotation	Perform	7,500	Perform	7,500
Battery Condition	Inspect	7,500	Inspect	Same As Normal
Drive Belt	Inspect	7,500	Inspect	Same As Normal
Vacuum Hose	Inspect	7,500	Inspect	Same As Normal
Drive Shaft & Boots	Inspect	15,000	Inspect	7,500
Air Cleaner Filter (Engine)	Inspect Replace	7,500 30,000	Replace	More Frequently
Climate Control Air Filter (for Evaporator & Blower Unit)	Replace	10,000 or 12 mos.	Replace	More Frequently
Air Conditioning Refrigerant	Inspect	15,000	Inspect	Same As Normal
Brake Hoses & Lines	Inspect	15,000	Inspect	Same As Normal
Brake Pads, Calipers & Rotors	Inspect	15,000	Inspect	More Frequently
Electronic Throttle	Inspect	15,000	Inspect	Same As Normal
Exhaust Pipe & Muffler	Inspect	15,000	Inspect	Same As Normal
Steering Gear Box, Linkage & Boots/ Lower Arm Ball Joint, Upper Arm Ball Joint	Inspect	15,000	Inspect	More Frequently
Suspension Mounting Bolts	Inspect	15,000	Inspect	Same As Normal
Fuel Tank Air Filter	Inspect Replace	15,000 30,000	Inspect Replace	Same As Normal Same As Normal
Automatic Transaxle Fluid	Inspect Replace	15,000 105,000	Replace	30,000
Coolant	1 st Replace Add'l Replace	60,000 or 60 mos. 30,000 or 24 mos.	Replace	Same As Normal
Brake Fluid	Inspect	15,000	Inspect	Same As Normal
Crankcase Ventilation Hose	Inspect	30,000	Inspect	Same As Normal
Fuel Lines, Fuel Hoses & Connections	Inspect	30,000	Inspect	Same As Normal
Manual Transaxle Fluid	Inspect	30,000	Replace	60,000
Rear Disc Brake Linings, Parking Brake	Inspect	15,000	Inspect	More Frequently
Vapor Hose & Fuel Filler Cap	Inspect	30,000	Inspect	Same As Normal
Fuel Filter	Replace	52,500	Replace	Same As Normal
Spark Plugs (Platinum Coated)	Replace	60,000	Replace	More Frequently
Tensioner/Idler - Timing Belt	Inspect	60,000	Replace	60,000
Valve Clearance	Inspect	60,000	Inspect	Same As Normal
Timing Belt	Inspect Replace	60,000 90,000	Replace	60,000
Spark Plugs (Iridium Coated)	Replace	100,000	Replace	More Frequently

*See Owner's Manual for details.

Looking For More Detailed Information? This Quick Reference Guide does not replace your vehicle's Owner's Manual. If you require additional information or are unsure of a specific issue, you should always refer to the vehicle's Owner's Manual or contact your authorized Hyundai dealer.

The information contained in this Quick Reference Guide was correct at the time of printing; however, specifications and equipment can change without notice. No warranty or guarantee is being extended in this Quick Reference Guide, and Hyundai reserves the right to change product specifications and equipment at any time without incurring obligations. Some vehicles are shown with optional equipment. Specifications apply to U.S. vehicles only. Please contact your Hyundai dealer for current vehicle specifications.



NP150-82010A
Rev 09/09/09
Print X/XX/09



HYUNDAI ELANTRA
QUICK REFERENCE GUIDE




www.hyundai.com

Roadside Assistance: **1-800-243-7766**
Consumer Affairs: **1-800-633-5151**
XM Radio: **1-800-967-2346**

Table of Contents

- Audio System 9
- AUX, USB and iPod® Input* .. 10
- Basic Safety Precautions..... 5
- Climate Control* 8
- Clock 11
- Cruise Control* 14
- ECO System 6
- Electronic Stability Control (ESC)* 15
- Front Seat Adjustment..... 6
- Headlights and Fog Lights* ... 7
- Headrest Adjustment..... 5
- Heated Seats* 12
- Occupant Classification System..... 12
- Power Mirror Control 4
- Rear Seat – Folding 6
- Refueling..... 12
- Remote Keyless Entry 4
- Shoulder Belt – Height Adjustment..... 5
- Steering Wheel Audio Controls* 10
- Sunroof Controls* 10
- Tilt and Telescopic Steering Wheel* 4
- Tire Pressure Monitoring System (TPMS)..... 15
- Transmission..... 13
- Trip Computer* 11
- Trunk Release 11
- Windshield Wiper/Washer..... 7



Electronic Stability Control (ESC)*
Page 15

Power Mirror Control
Page 4

Trunk Release
Page 12

Cruise Control*
Page 14

Heated Seats*
Page 12

AUX, USB, iPod® Input*
Page 10

Transmission
Page 13

Headlights and Fog Lights*
Page 7

Steering Wheel Audio Controls*
Page 10

Trip Computer*
Page 11

Windshield Wiper/Washer
Page 7

Clock
Page 11

Occupant Classification System
Page 12

Audio System
Page 9

Climate Control*
Page 8

*if equipped

Driver Control Features

Remote Keyless Entry

LOCK

Press:
Once – Lock
Twice – Confirmation chirp

UNLOCK

Press:
Once – Unlock driver door
Twice – Unlock all doors

TRUNK UNLOCK

Press and hold




PANIC

Press and hold.
Press any button to turn off panic.

Tilt and Telescopic Steering Wheel (if equipped)


NOTE: Do not adjust while driving.

1. Push the lever **A** downward.
2. Set the angle and height (if equipped).
3. Pull the lever **A** upward.



Power Mirror Control

1. Move the selecting switch **A** to the right or left.
Middle position: lock the control.
2. Depress the appropriate direction \blacklozenge on the switch.



Basic Safety Precautions


Whenever operating the vehicle, make sure that you and your occupants are properly wearing your seat belts. Small children should always ride in the rear seat in the appropriate child restraint system (see the Owner's Manual for child safety details).

Never place children under 13 years old in the front seats to avoid injury that may result from air bag deployment.


Always refer to your Owner's Manual for complete safety precaution information.

NOTE: If the driver's seat belt is not fastened when the ignition key is turned to the ON or START position, the seat belt reminder light will blink and the warning chime will sound for approximately six seconds to remind the driver to fasten the driver's seat belt.

Shoulder Belt – Height Adjustment




Headrest Adjustment



To adjust the headrest rearward, pull the headrest all the way forward, then release.


Driver Control Features (continued)

Front Seat Adjustment



Rear Seat – Folding

1. Pull out the seatback locking knob located in the trunk.
2. Fold the seat toward the front of the vehicle.



ECO Systems

ECO INDICATOR – AUTOMATIC TRANSMISSION

The ECO indicator light will illuminate when you drive with high fuel efficiency.

The ECO indicator can be turned off by selecting the function through the trip computer and pressing and holding for over 1 second ECO Off will then appear.

ECO SHIFT – MANUAL TRANSMISSION

▲ or ▼ symbol is displayed along with the gear number when reached at a specified RPM.

It indicates that you should up or down shift to specified gear.




Headlights and Fog Lights

HEADLIGHT SWITCH




- (1) OFF
- (2) Parking lights
- (3) Headlights

High beam ON




FOG LIGHT SWITCH (if equipped)



NOTE: Fog lights will only function on low beam.

Windshield Wiper/Washer



MIST – Single wipe

INT – Intermittent wipe.

*The wiper speed may be varied by rotating the INT switch .

LO – Low wiper speed

HI – High wiper speed

Climate Control (if equipped)



- A** Rotate for cooler or warmer temperatures.
- B** Rotate to select the blower speed.
- C** Rotate to direct the flow of air.
- D** Push to activate/deactivate recirculated cabin air.
- E** Press to defog the rear windows.

TO REMOVE FROST OR FOG ON THE WINDSHIELD

1. Set the temperature **A** to the desired setting.
2. Set the fan speed **B** to the highest setting.
3. Set the air flow **C** to the defrost position .

TO QUICKLY COOL THE VEHICLE

1. Set temperature **A** to the coldest setting.
2. Set the air flow control knob **C** to MAX A/C position. This automatically enables recirculation and front fan modes.

NOTE: If the Climate Control air filter for the evaporator blower is not replaced per the scheduled maintenance section, excessive window fogging may result. Your local authorized Hyundai dealer can replace this filter for you.

Audio System



SETTING PRESET MEMORY BUTTONS (AM/FM OR XM®)

1. Turn radio on by pressing the POWER button **A**.
2. Select AM/FM **C** or XM® radio **B**.
3. Turn the Audio Control knob **E** to the desired channel (for XM® press the knob to select the desired channel).
4. Press and hold any preset button **H** (1-6) until an audible beep is heard to memorize the current channel.

ADJUSTING THE EQUALIZER (SOUND QUALITY CONTROL)

1. Press the Audio Control knob **E** to select the following sound qualities: Equalizer→Bass→Middle→Treble→Balance→Fader→Current State
2. Turn the Audio Control knob **E** to adjust the sound quality.


NOTES:

- Please refer to your Owner's Manual for more detailed information on how to use your audio system.
- A clear view of the southern sky is recommended to ensure good XM® radio reception.

Complimentary XM® Subscription is for 90 days following the vehicle date of sale. Please contact XM® Radio at 1-800-XM-RADIO (1-800-967-2346) to renew your XM® subscription.

Additional Features

Steering Wheel Audio Control (if equipped)




AUX, USB and iPod® Input (if equipped)


You can connect a portable music device to the AUX, USB and iPod® port and hear the music stored on it through the vehicle speakers.

NOTE: The radio will not switch to the AUX mode unless a portable music device is connected.

NOTE: To receive all functions through the vehicle's Audio System when using an iPod®, a **Hyundai adapter cable** is required. This cable can only be purchased at your local Hyundai dealer.




Sunroof Controls (if equipped)



Trunk Release

PUSH TO OPEN TRUNK.



Trip Computer (if equipped)

TRIP COMPUTER (if equipped)


Each press of the TRIP button changes the display as follows:

- Tripmeter
- Distance to Empty
- Average Fuel Consumption
- Average Speed


NOTE: Press the TRIP button for more than one second to reset. Does not reset RANGE and ODOMETER.

TRIP ODOMETER (without trip computer)

Pressing the trip button cycles between Trip A and Trip B.



Clock



Press and hold both buttons to toggle between 12 or 24 hours.

Additional Features (continued)

Occupant Classification System

PASSENGER AIR BAG OFF INDICATOR

The occupant classification system will disable the right front passenger's air bag under certain conditions (light on).

The light will not illuminate when the passenger's air bag is enabled. Refer to your Owner's Manual for a complete description of this system.




Heated Seats (if equipped)

PUSH SWITCH TO WARM THE SEAT.




Refueling



NOTE: After adding fuel, always reinstall the fuel cap fully and make sure it clicks. Failure to do this may result in the Check Engine light illuminating.

Transmission


AUTOMATIC TRANSMISSION (if equipped)



- P** - Park
- R** - Reverse
- N** - Neutral
- D** - Drive
- 3** - Third Gear
- 2** - Second Gear
- L** - Low Gear

Normal forward driving is done with the shift lever in the D (Drive) position. To move the shift lever from the P (Park) position, the brake pedal must be depressed.

MANUAL TRANSMISSION (if equipped)



ENGAGING REVERSE

When shifting into R (Reverse) gear, lift the collar tab up and then shift into the R (Reverse) gear position.

Additional Features (continued)



Cruise Control (if equipped)

TO SET A CRUISING SPEED

1. Press **A** and the CRUISE indicator will illuminate in the instrument cluster. Accelerate to desired cruising speed (above 25 mph).
2. Press **B** and remove your foot from the accelerator pedal.

TO ACCELERATE OR DECELERATE SPEED

Press **C** to increase set cruising speed.
Press **B** to decrease set cruising speed.


TO CANCEL THE CRUISING SPEED

Press CANCEL **D** or press brake pedal, or press ON/OFF **A**.

Electronic Stability Control (ESC) (if equipped)

ESC OFF

Press the ESC button and ESC OFF will light up on the instrument panel. Press again for ESC ON.



Tire Pressure Monitoring System (TPMS)

LOW TIRE PRESSURE

Inflate tire(s) to proper pressure.

NOTE: Tire pressure may vary in colder temperatures causing the low tire pressure light  to illuminate.



INFLATE TIRE(S)

TPMS SYSTEM MALFUNCTION

See authorized Hyundai dealer.

NOTE: The TPMS is not a substitute for proper tire maintenance. Refer to your Owner's Manual for a complete description.



**SYSTEM MALFUNCTION
SEE DEALER**

